

roller deglazer gel 117A

For Higher Quality In Offset Printing



Print quality and profitability are directly related to the choice system components.

Application

The printcom roller deglazer gel 117A is a gel-like cleaning and regeneration agent for rollers and blankets.

It quickly and thoroughly removes deposits of water components (calcium carbonate) and improves the printing properties of the rubber.

Advantages

- Quick and thorough removal of calcium carbonate deposits on rollers and blankets
- Effective rubber regeneration
- Does not leave any residue on the cleaned surface
- Mild odor

Please, note:

printcom roller deglazer gel 117A is available in liquid form as:
printcom roller deglazer 116A.



Each printcom auxiliary product has been thoroughly tested by manroland's research and development departments for its press compatibility and performance.

If used as intended, these products will ensure efficient production processes, with the added benefit of preserving the life and value of your press.

printcom stands for “print competence” and represents manroland’s offering of process-compliant system components for the printing industry. Customer satisfaction is our top priority, and the printcom team is here to serve you.

Technical Data

Composition	gel
Color	orange, transparent
Specific Gravity at 20°C	1.036
Water-soluble	yes

Directions for Use

Rollers:
Apply a small amount of ready-made printcom roller deglazer gel 117A to the conventionally cleaned rollers. Let run idle for 5 to 10 minutes, apply more printcom roller deglazer gel 117A, should rollers run dry, and rinse off first with fresh, warm water, then with water-soluble wash.

Blankets:
Use printcom roller deglazer gel 117A undiluted on a clean rag to vigorously apply to the conventionally cleaned blankets. Let evaporate completely.

When using printcom roller deglazer gel 117A, please observe the safety instructions on the product label and material safety datasheet as well as the relevant regulations for the prevention of industrial accidents and other applicable rules!

Packaging Units

All packaging units are non-returnable.

Bottles	1 quart
---------	---------

Transport and Storage

cool and dry, protected against direct sunlight and freezing

Labeling

Health	2
Flammability	0
Reactivity	0
Protection	B

Augsburg.1.0809, us-englisch, roller deglazer gel 117A



manroland, Inc.
800 East Oak Hill Drive
Westmont, IL 60559
vox 630 920 2000
fax 630 321 3154
printcom@manroland.us
www.manroland.us

manroland